

OPTIONS

Flush Volume

1.6 gpf (6.0 Lpf) (1.6) 1.28 gpf (4.8 Lpf) (1.28)

Power Type

Battery Hardwired

Water Efficiency

Low Consumption High Efficiency

Bypass

Dual-Filtered Fixed Bypass Diaphragm

Override

True Mechanical (TMO)

Outlet Tube

Trap Primer (TP)

Bumper

Angle Stop (YO)

Compliances & Certifications

ADA Compliant
BAAA Compliant
UPC Certified
cUPC Certified
BREEAM Water Credit
Green Globes Water Credit

LEED V4 Water Efficiency Credit Satisfies LEED Credits

Satisfies LEED Credits

UL Certified

NOTES

For product line drawings, view model-specific spec sheets.

All information contained within this document subject to change without notice.



DESCRIPTION

Sloan® Exposed Sensor Water Closet Flushometer

FEATURES

- Flush volumes start as low as 1.6 gpf/6.0 Lpf
- Water conservation is aided by the ADA-compliant, non-holdopen handle, which prevents toilet from exceeding intended flush volume
- Flush accuracy is controlled by CID™ technology, also enhancing water efficiency
- Integrity of the product is maintained with the vandalresistant stop cap
- Durability is facilitated with high copper, low zinc brass castings for dezincification resistance
- Adjustable tailpiece to accommodate different height requirements
- High chloramine resistant PERMEX synthetic rubber diaphragm with Linear Filtered Bypass and Vortex Cleansing Action
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037.

DOWNLOADS

- Sloan Exposed Installation Instructions
- Sloan Exposed (Spanish) Installation Instructions
- EBV 200 Smooth Installation Instructions
- EL 600-A Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com





- Tail Piece Repair and Maintenance Guide
- Sloan Flushometer Repair and Maintenance Guide
- EBV-200-A Repair and Maintenance Guide
- EL600A Smooth Side Mount Repair and Maintenance Guide
- Additional Downloads