

#### **CODE NUMBER**

3453208

#### **DESCRIPTION**

1.0 gpf, Rough Brass Finish, Fixture Connection Rear Spud, Single Flush, 2-10.75 L Dimension, Electrical Override, Hardwired, Sensor-Operated, 24V, Royal® Concealed Sensor Hardwired Urinal Flushometer.

#### **DETAILS**

• Flush Volume: 1.0 gpf (3.8 Lpf)

• Finish: Rough Brass

Power Type: Hardwired (HW)

Valve: Diaphragm

• Valve Body Material: Semi-red Brass

• Fixture Type: Urinal

Fixture Connection: Rear Spud
Rough-In Dimension: 13 ½" (343mm)

• Spud Coupling: 3/4" (19mm)

• L Dimension: 2"-10 3/4" (51-273mm)

Override: ElectricalVoltage: 24V

• Supply Pipe: 3/4" (19mm)

#### **FEATURES**

Quiet, Concealed, Diaphragm Type, Rough Brass Urinal

- Handle Packing, Main Seat, Stop Seat and Vacuum Breaker Molded from PERMEX® Rubber Compound for Chloramine resistance
- User friendly three (3) second Flush Delay
- Fixed Metering Bypass and No External Volume Adjustment to Ensure Water Conservation
- "Walk By" Delay of Eight (8) Seconds Prevents Unintentional Flushes
- Vacuum Breaker Flush Connection with One-Piece Bottom Hex Coupling Nut, Spud Coupling and Flange for 3/4" Rear Spud
- 3/4" I.P.S. Wheel Handle Bak-Chek® Angle Stop

## **VIDEOS**

D

ESS Flushometer



#### **COMPLIANCES & CERTIFICATIONS**













(ADA Compliant, BAA Compliant, BABAA Compliant, cUPC Certified, UL Certified, UPC Certified)

#### RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

## **ELECTRICAL SPECIFICATIONS**

• Arming Delay: 8 seconds

• Control Circuit: Solid State/24 VAC Input/24 VAC Output

• Flush Delay: 1s

Self-Adaptive Window: ±8

• Sensor Range: 15"-30" (381-762mm)

• Solenoid Operator: 24 VAC

• Transformers (specify separately):

0345154

0345999

# **VALVE OPERATING PRESSURE (FLOWING)**

15–80 PSI (103–552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

# **DOWNLOADS**

- Royal ESS Concealed and Exposed Installation Instructions
- Royal 152/195 ESS TMO (Spanish) Installation Instructions
- Royal 152/195 ESS TMO Installation Instructions
- Royal 152/195 SWB ESS TMO (Spanish) Installation Instructions
- Optima Surface Mounted Sensor Activated Royal/Sloan Concealed Installation Instructions
- Royal 140/152/153/195 ESS TMO SWB Installation Instructions
- Royal ESS Concealed with Wall Box Installation Instructions
- Control Stop Repair and Maintenance Guide

Sloan 10500 Seymour Ave, Franklin Park, IL 60131

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Optima ESS Repair and Maintenance Guide
- Optima ESS TMO Concealed Repair and Maintenance Guide
- Optima ESS TMO SWB Concealed Repair and Maintenance Guide
- Additional Downloads

## NOTES


All information contained within this document subject to change without notice.

Looking for other variations of the ROYAL 195 ESS product? View the general spec sheet with all options.

### WARRANTY

View Warranty Information

### **ROUGH-IN**



Sloan 10500 Seymour Ave, Franklin Park, IL 60131

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com